

# PM66, PM70, PM80 Factory Reset

Factory reset erase all data from your device's internal storage.  
You have a problem with your device or you want to reset your device, you may use factory reset.

## APPLIES TO

PM66, PM70, PM80P

## How to Factory Reset PM66, PM70, PM80

- If you can turn on the device and use the Settings app,

1

Navigate to Settings > Backup & reset

2


Tap Factory data reset

3

Please be aware that factory reset will erase all data. Tap RESET PHONE to start the factory reset

4

Tap ERASE EVERYTHING to confirm the factory reset



- If you cannot turn on the device,

1

Press and hold Power + Volume Up + (PM70, PM80P)Home or (PM66)Front Scan buttons simultaneously when turning on the device

PM66	PM70	PM80P
------	------	-------



2


After short vibration, release the buttons. Now your device is entered Android Recovery mode

3

Using Volume(move up&down) and Power(select) buttons, select 'Wipe data/factory reset'

4

After wiping the data, select 'Reboot system now'





#### RELATED ARTICLES

- [Android Upgrade on Point Mobile Models](#)
- [How to Barcode Scanner Factory Reset](#)
- [PM30, PM67, PM75 Factory Reset](#)
- [PM351 Factory Reset](#)
- [PM45 Factory Reset](#)