

Turn On/Off barcode Data Wedge via Intent

APPLIES TO

Point Mobile devices running Android 6.0 and above

Turn On / Off Barcode Data Wedge via Intent

Try as follow code:

- Turn On

```
Intent intent = new Intent("device.common.ENABLED_SCANNER");  
intent.putExtra("EXTRA_ENABLED_SCANNER",1);  
  
context.sendBroadcast(intent);
```

- Turn Off

```
Intent intent = new Intent("device.common.ENABLED_SCANNER");  
intent.putExtra("EXTRA_ENABLED_SCANNER",0);  
  
context.sendBroadcast(intent);
```



RELATED ARTICLES

- [Get Scan Data in Ivanti \(Wavelink\) Velocity](#)