

# Check Link Speed

## APPLIES TO

All Point Mobile Android devices

## What is Link Speed?



Link speed is the **theoretical maximum speed** that the device can communicate to the linked router.

Link speed is not your actual speed from your Internet provider or the website that you are trying to download.

Actual speed is negotiated due to the provider's restrictions or the diffraction of wireless signals.

## How to Check Link Speed?

- 1. Go to **Settings > Network & internet > Wi-Fi**
- 2. Tap connected Wi-Fi
- 3. Find **link speed** from the network detail screen.  
If you are using the version above Android 8, you may need to expand **Advanced**.

Under Android 8	Android 9 and above
	



### RELATED ARTICLES

- [Wi-Fi Privacy \(Randomized MAC\) Setting in Android 10 or higher](#)
- [Backup and Restore Wireless Network Profiles using Direct Clone](#)
- [Wi-Fi Scan Throttling Setting](#)
- [Enhanced Security, WPA3 Support](#)
- [What is Keep Alive Mode in WLAN Detail settings?](#)

