PM66, PM70, PM80 Factory Reset

Factory reset erase all data from your device's internal storage.

You have a problem with your device or you want to reset your device, you may use factory reset.

APPLIES TO

PM66, PM70, PM80P

How to Factory Reset PM66, PM70, PM80

- If you can turn on the device and use the Settings app,

1. Navigate to Settings > Backup & reset
2. Tap Factory data reset
3. Please be aware that factory reset will erase all data. Tap RESET PHONE to start the factory reset
4. Tap ERASE EVERYTHING to confirm the factory reset

- If you cannot turn on the device,

1. Press and hold Power + Volume Up + (PM70, PM80P)Home or (PM66)Front Scan buttons simultaneously when turning on the device

PM66	PM70	PM80P

2 After short vibration, release the buttons. Now your device is entered Android Recovery mode

3 Using Volume(move up&down) and Power(select) buttons, select 'Wipe data/factory reset'

4 After wiping the data, select 'Reboot system now'

RELATED ARTICLES

- Android Upgrade on Point Mobile Models
- How to Barcode Scanner Factory Reset
- PM30, PM67, PM75 Factory Reset
- PM351 Factory Reset
- PM45 Factory Reset