

Reconnect PM3 to Host Device

ISSUE

After the connection between the PM3 and the host device is lost, PM3 doesn't automatically reconnect to host device

APPLIES TO

PM3



When the connection is lost, **press DOWN button 2~3 seconds to try to reconnect.**

This feature, named **HID Reconnect**, can be used only in HID mode and is enabled by default.

How to Set HID Mode?

1. Press **UP** and **DOWN** simultaneously to navigate to **Setting**
2. Go to **User Settings > Connect Mode**
3. Select **HID Normal**
4. Select **Save** and wait to complete initializing

How to Enable HID Reconnect?

1. Press **UP** and **DOWN** simultaneously to navigate to **Setting**
2. Go to **Admin Menu > Bluetooth > HID Settings**
3. Select **HID Reconnect**
4. Select **Enabled** and **Save**



HID Reconnect

- The setting is enabled by default.
- The setting only can be used in HID mode. 'Only Used in HID Mode' message will be displayed when you access this setting in SPP or iOS mode.



RELATED ARTICLES

- [\[PM3\] Reading count is displayed '0' only](#)
- [\[PM3\] Cannot get scan data](#)
- [PM3 Reset Date & Time after Rebooting](#)
- [Changed PM3 Comparison](#)
- [Except for Non-printable characters from Decoded data \(PM3\)](#)

